

**Proposed legal text for amendments to paragraph 2.1.5(c) and paragraph 3.1.6(b)(ii) of TPD  
Section B**

2.1.5 In respect of an Aggregate System Entry Point and in relation to a Day in a calendar month in a Formula Year:

....

(c) "**Unsold NTS Entry Capacity**" [subject to EID Section E, paragraph 7.1.4](#), is the amount of Firm NTS Entry Capacity that National Grid NTS has an obligation to make available (in accordance with the procedures set out in this paragraph 2) to Users pursuant to Special Condition 5F of National Grid NTS's Transporter's Licence as, in the case of NTS Entry Capacity to be made available under paragraphs 2.2, 2.3 and 2.4 but not paragraph 2.5, set out in National Grid NTS's Transportation Statement, for the purposes of:

(i) paragraph 2.2, in relation to each Day in a calendar quarter (in the case of QSEC) or in a month (in the case of AMSEC);

(ii) paragraph 2.3, in relation to each Day in a calendar month;

(iii) paragraph 2.4, in relation to a Day; in each case minus Reserved Entry Capacity for the calendar quarter, calendar month or Day in question.

...

3.1.6 For the purposes of the Code:

...

(b) in respect of an NTS Exit Point and in relation to a Gas Year:

(i) the "**Baseline NTS Exit (Flat) Capacity**" is the amount of NTS Exit (Flat) Capacity which National Grid NTS is required to make available to Users in relation to each Day in that Gas Year (or part thereof) pursuant to National Grid NTS's Transporter's Licence and as set out in National Grid NTS's Exit Capacity release obligation summary report;

(ii) [subject to EID Section E, paragraph 7.1.4](#), at any time the "**Remaining Available NTS Exit (Flat) Capacity**" in relation to that Gas Year or (as the case may be) a Day in that Gas Year is the amount (if any) by which the Baseline NTS Exit (Flat) Capacity for that Gas Year exceeds the aggregate amount of NTS Exit (Flat) Capacity registered, at that time, as held by Users in relation to that Gas Year or Day (Reserved NTS Exit Capacity shall be treated (for the purposes only of determining the Remaining Available NTS Exit (Flat) Capacity) as if it were registered as held by a User);