

Attachment #10

UNC reference: TPD Section B (new paragraph)
Subject: Moffat Discounted rate
Relevant alternates: 0678I (Gazprom)

New paragraph 9

9 Moffat Discounted Rate

9.1 General

9.1.1 Where a User delivers gas to and offtakes gas from the NTS at (respectively) an Eligible Entry Point and the NTS Exit Point at Moffat (the "**Moffat Exit Point**"), the User may elect to pay the Moffat Discounted Rate of the Capacity Charge for a certain amount of NTS Exit (Flat) Capacity, subject to and in accordance with this paragraph 8 (a "**Moffat DR Election**").

9.1.2 For the purposes of this paragraph 8:

- (a) an "**Eligible Entry Point**" is an Aggregate System Entry Point which is not a Storage Connection Point, an Interconnection Point or an LNG Importation Terminal Point;
- (b) where a User has made a Moffat DR Election, the "**Specified Entry Point**" is the Eligible Entry Point for which the User has made such election.

9.2 Procedure

9.2.1 For the purposes of this paragraph 8:

- (a) a User may give notice to National Grid NTS of a Moffat DR Election, specifying the Eligible Entry Point;
- (b) a User may terminate a Moffat DR Election by notice to National Grid NTS specifying the effective date of termination, which shall not be less than 15 Days or more than 6 months after the date of such notice;
- (c) a Moffat DR Election shall remain in force until terminated under paragraph (b);
- (d) notices between a User and National Grid NTS under this paragraph 8.2 shall be given by Conventional Notice.

9.2.2 A User may not make a Moffat DR Election in respect of more than one Eligible Entry Point.

9.3 Determination of charges payable

9.3.1 Where a User has made a Moffat DR Election, for each Day for which such election is in force:

- (a) the "**Applicable Moffat Daily Quantity**" is whichever is the least of:
 - (i) the sum of the User's UDQIs for each System Entry Point within the Specified Entry Point;
 - (ii) the User's UDQO for the Moffat Exit Point;
 - (iii) the User's Registered NTS Exit (Flat) Capacity at the Moffat Exit

Point;

or if more than one of them are equally low, the User's Registered NTS Exit (Flat) Capacity at the Moffat Exit Point;

- (b) the "**Residual Moffat Daily Capacity**" is the amount (if any) by which the User's Registered NTS Exit (Flat) Capacity at the Moffat Exit Point exceeds the Applicable Moffat Daily Quantity;

9.3.2 Where a User has made a Moffat DR Election, for each Day, the User shall pay, in respect of NTS Exit (Flat) Capacity at the Moffat Exit Point, Capacity Charges:

- (a) at the Moffat Discounted Rate, in respect of the Applicable Moffat Daily Quantity;
- (b) at the full Applicable Daily Rate, in respect of the Residual Moffat Capacity;

9.3.3 Where the User holds Registered NTS Exit (Flat) Capacity at the Moffat Exit Point pursuant to more than one allocation of such NTS Capacity, and for which the Applicable Daily Rates of the NTS Exit Capacity Charges are different, for the purposes of paragraph [8.3.2] the Applicable Moffat Daily Quantity shall be apportioned in proportion to such holdings and for each such holding the Residual Moffat Daily Capacity shall be calculated accordingly.