

RT_U02_UNBUNDLED_READ_REJECTION

(Rejection details for a System User supplied Unbundled Meter Read)

<u>RECORD/FIELD NAME</u>	<u>OPT</u>	<u>DOM</u>	<u>LNG</u>	<u>DEC</u>	<u>DESCRIPTION</u>
TRANSACTION_TYPE	M	T	3	0	DEFINITION: A code identifying the type of transaction that this record represents. VALUE: U02
METER_POINT_REFERENCE	M	N	10	0	DEFINITION: A unique identifier for the point at which a meter is, has been or will be connected to the gas network. These references are less volatile than meter or service identifiers and do not change if the meter is replaced or the service is relayed to the same position. New Meter Point References will only be created for new services or when a service is related to a different position. CONTEXT: The reference of the Meter Point which the meter / corrector reads relate to.
ACTUAL_READ_DATE	M	D	8	0	DEFINITION: The date on which the read was taken. FORMAT: YYYYMMDD
METER_READING_SOURCE	M	T	1	0	DEFINITION: The source from which the read was taken. VALUES: M - Meter Read Organisation E - Supplied by the End User A - Agreed Opening Read R - Remote Reading Equipment Read Q - Shipper Provided Estimated Read G - Gas Card Read P - Point of Sale Read
METER_READING_REASON	M	T	1	0	DEFINITION: The reason why the read was taken. VALUES: O - Opening Read R - Replacement Read N - Non Opening Read
METER_SERIAL_NUMBER	M	T	14	0	DEFINITION: The manufacturers meter serial number. CONTEXT: The serial number of the meter from which the meter read was taken.
METER_READING	M	T	12	0	DEFINITION: The actual index read from the meter.

.URS

Section 5 SPA SID
© 2000 Transco plc

.U02

**For Approval - Version 4
Issued: 17th June 2005**

FORMAT: The index should be right justified and be the same length as the number of digits/dials present on the meter.

This may mean the index provided is left padded with zeros to equate the length of the values to the actual number of digits/dials. Where the number of digits/dials is less than 12 the remaining characters should be set to spaces e.g. for a 4 digit dial display the index would be formatted as ' 0012'

METER_ROUND_THE_CLOCK_COUNT	O	T	2	0	DEFINITION: Number of times the meter has gone round the clock i.e. through the zeros. VALUES: blank, -9 through to 99
METER_READ_VERIFIED	O	T	1	0	DEFINITION: Indicates whether the meter read has failed the System User tolerance checking but is being accepted. VALUES: Y or blank
CORRECTOR_SERIAL_NUMBER	O	T	14	0	DEFINITION: The manufacturers corrector serial number. CONTEXT: The serial number of the corrector from which the corrector reads were taken.
CORRECTOR_UNCORRECTED_READING	O	T	12	0	DEFINITION: The uncorrected index taken from the corrector. FORMAT: The index should be right justified and be the same length as the number of digits/dials present on the meter. This may mean the index provided is left padded with zeros to equate the length of the values to the actual number of digits/dials. Where the number of digits/dials is less than 12 the remaining characters should be set to spaces e.g. for a 7 digit dial display the index would be formatted as ' 0012345'
CORRECTOR_CORRECTED_READING	O	T	12	0	DEFINITION: The corrected index taken from the corrector. FORMAT: The index should be right justified and be the same length as the number of digits/dials present on the meter. This may mean the index provided is left padded with zeros to equate the length of the values to the actual number of digits/dials. Where the number of digits/dials is less than 12 the remaining characters should be set to spaces e.g. for a 7 digit dial display the index would be formatted as ' 0012345'
CORRECTOR_ROUND_THE_CLOCK_COUNT	O	T	2	0	DEFINITION: The number of times the corrector has gone round the clock i.e. through the zeros.

VALUES: blank, -9 through to 99

CORRECTOR_USABLE_IND	O	T	1	0	DEFINITION: Indicates whether the corrector reads are usable for billing purposes. VALUES: Y, N or blank. If blank and corrector is fitted, Y will have be assumed during the validation process.
CORRECTOR_READ_VERIFIED	O	T	1	0	DEFINITION: Indicates whether the corrector read has failed the System User tolerance checking but is being accepted. VALUES: Y or blank
SERIAL_NUMBER_MATCH	M	T	1	0	DEFINITION: Indicates which METER_SERIAL_NUMBER matching routine was used to compare the shipper supplied SERIAL_NUMBER against the value held on the Sites & Meters database. Set according to the result of the METER_SERIAL_NUMBER matching routine, part of the Unbundled METER_READ validation process. VALUES: E - The supplied value used the Exact match logic. F - The supplied value used the Fuzzy match logic. R - The SERIAL_NUMBER match failed. N - The Serial Number validation was not performed.
MET_SERIAL_NUMBER_TRANSCO	O	T	14	0	DEFINITION: Serial number of meter for which read was taken, as held on system. This will be populated when Fuzzy match was used or when SERIAL_NUMBER_MATCH failed.
PREV_MET_SERIAL_NUMBER	O	T	14	0	DEFINITION: This field will be populated by TRANSCO only if the reading is rejected due to the shipper MSN being a previous one. The field contains the <u>Previous</u> MSN as on the S&M database

* 123
