

UK-LINK SITES AND METERS DATABASE
METER READING AND ACCESS INSTRUCTIONS FILE/NOMINATION/REFERRAL

RESPONSE/NOMINATION RESPONSE / CONFIRMATION RESPONSE FILE

RECORD LAYOUTS

RT _ K14 _ ADDTNL _ METERING _

(Additional Metering Details)

RECORD/FIELD NAME	OPT	DOM	LNG	DEC	DESCRIPTION
TRANSACTION_TYPE	M	T	3	0	DEFINITION: A code identifying the type of request that this record represents. VALUE: K14
METER_TYPE	O	T	1	0	DEFINITION: The type of meter. Values -R = Rotary -T = Turbine -D = Diaphragm of unknown material -L = Leather Diaphragm -S = Synthetic Diaphragm -U = Ultrasonic -Z = Unknown
METER_MODEL_NAME	O	T	1	0	DEFINITION: The model description for the (e.g. -2-U6-2-U16-2-102M12- or -2-G2500-).
METER_MANUFACTURER	O	T	3	0	DEFINITION: The code of the manufacturer of the meter.
METER_MANUFACTURED_YEAR	O	N	4	0	DEFINITION: The year in which the meter was manufactured expressed as a century date (1981).
IMPERIAL_METER_INDICATOR	O	T	1	0	DEFINITION: Indicator identifying if the meter measures volume of gas consumed in metric or imperial units. Allowable values when present:- Y = Imperial meter N = Metric meter
METER_READING_UNITS	O	N	5	0	DEFINITION: This contains the units the meter is read in e.g. 10,100, 1000 Cubic Feet
CORRECTOR_MODEL_NAME	O	T	1	0	DEFINITION: The model description for the (e.g. -2-U6-2-U16-2-102M12- or -2-G2500-).
CORRECTOR_MANUFACTURER	O	T	3	0	DEFINITION: The code of the manufacturer of the corrector.
CORRECTOR_MANUFACTURED_YEAR	O	N	4	0	DEFINITION: The year in which the meter was manufactured expressed as a century date (1981).
CORRECTOR_CORRECTED_READING_UNITS	O	N	5	0	DEFINITION: This contains the units the corrected corrector reading reads in, e.g.g. 10s, 100s, 1000s cubic feet.

|

CORRECTOR_
UNCORRECTED_READING_UNITS

O ___N___-5 ___0

DEFINITIONS: This contains the units the
uncorrected corrector reading reads in,
e.g. 10s, 100s, 1000s cubic feet.

* 64

